

Lab 05: OpenCV and Depth Sensing

By Michael Su, Wolf Chen, last modified on 03/29 2020

The objective of this tutorial is to introduce the concept of point cloud, depth camera, and examples for OpenCV.

In topic 1, you will learn how to use Realsense camera SR300 or D435 and understand the content of published topics.

In topic 2, we will use OpenCV functions and detect objects with HSV color space.

Hardware and software setup

Laptop setup

Update the latest repo to laptop

```
laptop$ cd ~/sis_lab_all_2020 (If you haven't clone repo, please clone it first.)
```

```
laptop$ git checkout devel-[student_id] (create and switch to your branch)
```

```
laptop$ git stash
```

```
laptop$ git pull origin master
```

```
laptop$ git stash pop
```

```
laptop$ cd ~/sis_lab_all_2020/05-Opencv_and_Depth_Sensing/Dockerfiles/PC
```

```
laptop$ docker build -t="lab5" .
```

^ there is a dot here.

Nano setup

Please turn on Nano and plug your Realsense Camera into Nano.

Then, open a terminal and SSH into Nano.

```
laptop$ ssh arg@[hostname].local
```

First, set Jetson Nano from 5 Watt mode into 10 Watt mode to increase the computational speed

```
Nano$ sudo nvpmodel -m 0
```

Delete all the docker images, containers on Nano

```
Nano$ docker rm -vf $(docker ps -a -q)
```

```
Nano$ docker rmi -f $(docker images -a -q)
```

```
Nano$ cd ~/sis_lab_all_2020 (If you haven't clone repo, please clone it first.)
```

```
Nano$ git checkout master
```

```
Nano$ git stash && git pull
```

```
Nano$ cd ~/sis_lab_all_2020/05-Opencv_and_Depth_Sensing
```

```
Nano$ docker build -t="lab5" -f=Dockerfiles/Nano/Dockerfile .
```

^ there is a dot here.

Hardware and software setup	1
Laptop setup	1
Nano setup	1
Overview	2
Topics and Activities	3
Topic 1: Use RGB-D Camera	3
Discussion and Check point	5
Topic 2: Pin hole projection	5
Topic 2.1: Get point 3D coordinate from depth	5
Discussion.	6
Bonus. Analyze detected object	8
Task 1: Detect multi objects and draw contours	8
Task2: Determine object shape	8
Task3: Calculate object size	9
Reference	10

Overview

Estimated Time to Finish: 1.3 hours

After completing this tutorial you should

- be able to
 - run RealSense Camera
 - use ROS topics from RealSense Camera
 - use OpenCV
- know
 - how pointcloud is generated.
 - what is Morphological Image Processing
 - what is camera matrix
 - what is HSV color space

Topics and Activities

Topic 1: Use RGB-D Camera

Open a terminal and SSH into Nano.

```
Laptop$ ssh arg@[your nano hostname].local
```

```
Nano$ export DISPLAY=:0 && xrandr --fb 1800x900 ( Resolution depends on your screen)
```

```
Nano$ /usr/lib/vino/vino-server
```

Open the other terminal

```
laptop$ vncviewer -quality 5 -encodings "tight" [your nano hostname].local
```

Open a terminal in Nano

```
Nano$ xhost +
```

```
Nano$ source
```

```
~/sis_lab_all_2020/05-Opencv_and_Depth_Sensing/Dockerfiles/docker_run_nano.sh
```

```
Nano Container$ source devel/setup.bash
```

```
Nano Container$ roslaunch realsense2_camera rs_rgbd.launch
```

Open the second terminal in Nano


```
Nano$ rviz
```

Please set fixed frame as camera_link

Add topic `"/camera/depth_registered/points"`,

`"/camera/aligned_depth_to_color/image_raw/raw"`, `"/camera/color/image_raw/raw"`

You need to modify fixed frame from **map** to **camera_link**, otherwise, you won't see the point cloud.



Open the third terminal in Nano

Nano\$ docker exec -it lab5 bash (Enter container bash)

Nano Container\$ rostopic list (List all ROS topics)

```
root@tx2-14:/home/nvidia/sis_lab_all# rostopic list
/camera/camera_nodelet_manager/bond
/camera/depth/camera_info
/camera/depth/disparity
/camera/depth/image
/camera/depth/image/compressed
/camera/depth/image/compressed/parameter_descriptions
/camera/depth/image/compressed/parameter_updates
/camera/depth/image/compressedDepth
/camera/depth/image/compressedDepth/parameter_descriptions
/camera/depth/image/compressedDepth/parameter_updates
/camera/depth/image/theora
/camera/depth/image/theora/parameter_descriptions
/camera/depth/image/theora/parameter_updates
/camera/depth/image_raw
/camera/depth/image_raw/compressed
/camera/depth/image_raw/compressed/parameter_descriptions
/camera/depth/image_raw/compressed/parameter_updates
/camera/depth/image_raw/compressedDepth
/camera/depth/image_raw/compressedDepth/parameter_descriptions
/camera/depth/image_raw/compressedDepth/parameter_updates
/camera/depth/image_raw/theora
/camera/depth/image_raw/theora/parameter_descriptions
/camera/depth/image_raw/theora/parameter_updates
/camera/depth/image_rect
/camera/depth/image_rect/compressed
/camera/depth/image_rect/compressed/parameter_descriptions
/camera/depth/image_rect/compressed/parameter_updates
/camera/depth/image_rect/compressedDepth
/camera/depth/image_rect/compressedDepth/parameter_descriptions
/camera/depth/image_rect/compressedDepth/parameter_updates
```

Nano Container\$ rostopic echo /camera/color/camera_info

```
header:
  seq: 18348
  stamp:
    secs: 1538712625
    nsecs: 435345569
  frame_id: "camera_rgb_optical_frame"
height: 480
width: 640
distortion_model: "plumb_bob"
D: [0.0, 0.0, 0.0, 0.0, 0.0]
K: [620.5628662109375, 0.0, 314.2391052246094, 0.0, 620.5629272460938, 240.24301147460938, 0.0,
0.0, 1.0]
R: [1.0, 0.0, 0.0, 0.0, 1.0, 0.0, 0.0, 0.0, 1.0]
P: [620.5628662109375, 0.0, 314.2391052246094, 0.0, 0.0, 620.5629272460938, 240.24301147460938,
0.0, 0.0, 0.0, 1.0, 0.0]
binning_x: 0
binning_y: 0
roi:
  x_offset: 0
  y_offset: 0
  height: 0
  width: 0
  do_rectify: False
```

Discussion and Check point

- [illegible]


Note: After you finished topic 1, please exit docker container, so the docker container will be automatically removed.

Topic 2: Pinhole projection

Topic 2.1: Get point 3D coordinate from depth

Suppose we have a depth image, the value of each pixel represents the real depth between camera and the captured point in the real world. Now we get random pixel of the image. With algorithm 1, we can get 3D coordinate from point depth.

Algorithm 1



Pin hole projection illustration.

$$\begin{bmatrix} x_p \\ y_p \\ 1 \end{bmatrix} = K \begin{bmatrix} x_c/z_c \\ y_c/z_c \\ 1 \end{bmatrix} \quad K = \begin{bmatrix} f_x & 0 & c_x \\ 0 & f_y & c_y \\ 0 & 0 & 1 \end{bmatrix}$$

Transform matrix

Open a terminal in Nano vncviewer

Nano\$ source

```
~/sis lab all 2020/05-Opencv and Depth Sensing/Dockerfiles/docker run nano.sh
```

You can go to checkout the information in this file

```
Nano Container$ source devel/setup.bash
```

```
Nano Container$ roslaunch realsense2_camera rs_rgbd.launch
```

Open a terminal in Nano vncviewer

```
Nano$ cd ~/sis_lab_all_2020/05-Opencv_and_Depth_Sensing/catkin_ws
```

```
Nano$ catkin_make
```


Please ignore the error

```
Nano$ source devel/setup.bash
```

```
Nano$ rosrn me212cv object_detection.py
```

You will see the the following image:

OpenCV View: RGB image



Discussion.

1. Show the results of the topic 2.1
2. Please explain the code in function “getXYZ”
3. Given a depth image, in image(20,20), the value is 0.5. Please use algorithm 1 and parameters from ROS topic “/camera/color/camera_info” to calculate the real world coordinate (x,y,z)

Topic 3.1: HSV filtering

HSV filtering is a common and easy method to detect colored objects. In topic 3.1, we will filter red object by using HSV color space. Then, we will use morphology image process skills to denoise and make mask complete. Finally, with separate object mask, we can get object contour and its bounding box.

In Nano container, change the variables in
05-Opencv_and_Depth_Sensing/catkin_ws/src/me212cv/scripts/object_detection.py
“useHSV” as **True**, “useDepth” value as **False**


Open a camera launch file in Nano container

Nano Container\$ `roslaunch me212cv object_detection.py`

Add the topic “/camera/color/image_rect_color”, “/object_detection/mask_eroded”,
“/object_detection/mask_eroded_dilated”, “/object_detection/img_result”

You will see the the following image:

Rviz: the detected object



Bonus. Analyze detected object



In tutorial, we are able to detect objects by using HSV color space. In bonus, we will start to analyze objects. Each group will be given a paper where red square, equilateral triangle, circle are printed. Our mission is to detect each object, get the shape, and calculate the area.


In task 1, we will detect objects by using the same method as tutorial, but we will draw the contours instead of bounding box.

In task 2, the shape of object needs to be determined. That is, you need to get the number of object vertex. Now you have had the contours of the object. All you need to do is approximate the contours as polygon. (hint: use opencv function **approxPolyDP**)

In task 3, after determining the object shape, we can know which formula to use to calculate object area. Your mission is to get side length or radius and then you can use the already prepared function to calculate object area. (You don't need to implement algorithms for calculating area.)

Task 1: Detect multi objects and draw contours


In task 1, you will revise `object_detection.py` and finish line 144 - 148. You also need to set variable `"draw_contours"` as `"True"` if you want to demo.



Topic `"/object_detection/img_result"`

Task2: Determine object shape

In task 2, you need to detect object shape for each object (contour). You also need to set variable “draw_contours” and “detect_shape” as “True” if you want to demo.



Topic “/object_detection/img_result”

Task3: Calculate object size

In task 3, we offer the methods to calculate area. If you want to use the method TA offers, you will need to assign vertex list of single object to variable "vtx_list" and finish functions "get_side_length", "get_radius". You can also write your own code to calculate area. If so, please ignore and comment the line 193 - 218.

You also need to set variable "draw_contours", "detect_shape", and "calculate_size" as "True" if you want to demo.


(Note: The area doesn't need to be the same as expected result. The result will be regarded to be successful if error is lower than 10%.)

Groundtruth:

Equilateral triangle: 0.0010825m^2

Square: 0.0025 m^2

Circle: 0.0019635 m^2



Topic "/object_detection/img_result"

Grading rule

The homework template will be announced on New E3

Reference

- <https://www.jetsonhacks.com/2019/04/10/jetson-nano-use-more-power/>
- <http://people.csail.mit.edu/peterkty/teaching.htm>
- http://docs.opencv.org/2.4/modules/calib3d/doc/camera_calibration_and_3d_reconstruction.html?highlight=calibratecamera
- http://wiki.ros.org/rgbd_launch
- http://docs.ros.org/api/sensor_msgs/html/msg/CameraInfo.html